```
配置简介
Cisco
   Nexus 系列交换机
      三层 MTU
      二层MTU
      验证
         三层 MTU
         二层 MTU
   Catalyst 4500系列交换机
      二层接口MTU (只能全局配置)
      三层接口MTU
   2960、3560、3750
      全局配置GigabitEthernet接口MTU
      三层接口 MTU
  大包测试
华为
   <u>S1700, 2700, 5700, CE系列</u>
      二层接口MTU
      三层MTU
华三
   $6300, $5800, $7500, $10500, $5120
      二层接口MTU
     三<u>层MTU</u>
锐捷
   S8610
     三层接口MTU
   检查
```

摘要:在使用基于 VXLAN 的 SDN 解决方案时,对物理网络的基本要求是修改 MTU,让其大于 1600 (NSX),下面总结了几大厂商不同型号或版本交换机的配置,以后会不断更新,也请有过配置经验的同行帮忙补充

配置简介

一般配置 MTU 时,需要配置端到端沿途所有设备,如果源和目标在同一个网段,则只需要配置沿途所有设备的二层接口MTU。一般按照设备不同,可能需要全局配置 MTU,或者在对应接口上配置 MTU。

如果源和目的在不同的网段内,除了配置沿途所有二层接口 MTU 外,还需配置两个网段网关接口(三层接口)的 MTU。

一般配置方式是 interface vlan 100, mtu 1600。

Cisco

Nexus 系列交换机

参考资料: https://www.cisco.com/c/en/us/support/docs/switches/nexus-9000-series-switches/118994-config-nexus-00.html

三层 MTU

SVI 接口配置:

```
Switch(config)#interface vlan 1
Switch(config-if)#mtu 9216
```

三层物理接口配置:

```
Switch(config)#interface ethernet 1/1
Switch(config-if)#no switchport
Switch(config-if)#mtu 9216
```

二层MTU

二层MTU可以通过Qos或者基于端口进行配置。目前只有 Nexus 7000, 7700, 9300, 和 9500 支持端口配置 MTU。

Nexus 3048, 3064, 3100, 3500, 5000, 5500, 及 6000 配置方式 此配置会对所有接口生效

```
policy-map type network-qos jumbo
  class type network-qos class-default
    mtu 9216
system qos
  service-policy type network-qos jumbo
```

Nexus 7000, 7700, 9300, 及 9500 配置方式

以下为基于接口的配置方式:

```
Switch(config)#interface ethernet 1/1
Switch(config-if)#mtu 9216
```

Nexus 2000 配置

注意,Nexus 2000 MTU 配置需要在其父 FEX 交换机上进行配置,如果父交换机支持接口下配置MTU,则在对应接口下配置,如果不支持,则需要使用**network-qos**。

需要注意,使用 FEX 时,Fabric Port Channel (FPC) ,也就是连接 FEX 的端口聚合组也需要配置 MTU

```
interface port-channel136
  switchport mode fex-fabric
  fex associate 136
  vpc 136
  mtu 9216
```

注意: 在 6.2 版本以后,Nexus 7000 不支持给 Fabric Port Channel 接口直接配置MTU,必须创建一个 QoS 策略来全局调整 MTU。

```
policy-map type network-qos jumbo
  class type network-qos class-default
   mtu 9216
system qos
  service-policy type network-qos jumbo
```

验证

三层 MTU

所有 Nexus 系列交换机都可以通过 show interface eth x/y 命令来查看接口 MTU:

```
Nexus#show interface ethernet 1/19
Ethernet1/19 is up
Dedicated Interface
Hardware: 100/1000/10000 Ethernet, address: 547f.ee5d.413c (bia 547f.ee5d.40fa)
MTU 9216 bytes, BW 1000000 Kbit, DLY 10 usec
```

使用 Show interface vlan X 命令查看 SVI 接口MTU:

```
Leaf3#show interface vlan 1
Vlan1 is down (Non-routable VDC mode), line protocol is down
Hardware is EtherSVI, address is 547f.eed8.ec7c
Internet Address is 1.1.1.1/23
MTU 9216 bytes, BW 1000000 Kbit, DLY 10 usec
```

二层 MTU

Nexus 3100, 3500, 5000, 5500, 及 6000

```
Nexus#show queuing interface ethernet 1/1
Ethernet1/1 queuing information:

TX Queuing

qos-group sched-type oper-bandwidth

0 WRR 100

RX Queuing

qos-group 0

q-size: 469760, HW MTU: 9216 (9216 configured)
```

Nexus 3000, 7000, 7700, 及 9000

```
Nexus#show interface ethernet 1/12
Ethernet1/12 is up
admin state is up, Dedicated Interface
Hardware: 1000/10000 Ethernet, address: 7c0e.ceca.f183 (bia 7c0e.ceca.f183)
MTU 9216 bytes, BW 10000000 Kbit, DLY 10 usec
```

Nexus 5000, 6000, 及 7000 的 FEX 接口

```
Nexus#show queuing interface ethernet 136/1/1
if slot 68, ifidx 0x1f870000
Ethernet136/1/1 queuing information:
 Input buffer allocation:
 Qos-group: 0
 frh: 3
 drop-type: drop
 cos: 0 1 2 3 4 5 6 7
 xon xoff buffer-size
 -----
 19200 78080 90880
 Queueing:
 queue qos-group cos
                           priority bandwidth
0
                   0 1 2 3 4 5 6
                                WRR 100
                                              9280
```

Nexus 9000 的FEX 接口

```
9396-B#show interface ethernet 104/1/1
Ethernet104/1/1 is up
admin state is up,
Hardware: 100/1000 Ethernet, address: 5475.d0e0.e5c2 (bia 5475.d0e0.e5c2)
MTU 9216 bytes, BW 1000000 Kbit, DLY 10 usec
```

Catalyst 4500系列交换机

已知可用交换机版本: C4506 IOS 12.2

Cisco C4500系列交换机请检查板卡兼容性,一些老设备可能无法支持MTU>1570 https://www.cisco.com/c/en/us/support/docs/switches/catalyst-4000-series-switches/29805-175.html#topic3

二层接口MTU(只能全局配置)

```
system mtu 1600
```

检查命令: show system mtu 或者

```
Show interface G0/0

GigabitEthernet1/3 is up, line protocol is up (connected)

Hardware is Gigabit Ethernet Port, address is 588d.097e.9982 (bia 588d.097e.9982)

MTU 1600 bytes, BW 1000000 Kbit, DLY 10 usec,

reliability 255/255, txload 6/255, rxload 21/255

Encapsulation ARPA, loopback not set
```

三层接口MTU

interface vlan 200 mtu 9000

2960、3560、3750

2960 IOS 12.2, 3560 12.2, 3750 15.0

全局配置FastEthernet接口MTU:

system mtu 1600

全局配置GigabitEthernet接口MTU

(如果不配置,则继承system mtu配置):

system mtu jumbo 1600

三层接口 MTU

全局: system mtu routing 1600

接口下(接口下优先):

interface vlan 100 mtu 1600

大包测试

```
!-- 从交换机SW1 ping SW2, 1570 字节的包,成功
SW1#ping 192.168.12.2 size 1550 df-bit
Type escape sequence to abort.
Sending 5, 1550-byte ICMP Echos to 192.168.12.2, timeout is 2 seconds:
Packet sent with the DF bit set
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/202/1006 ms
```

```
!-- 从交换机SW1 ping SW2 , 1600 字节的包,失败

SW1#ping 192.168.12.2 size 1600 df-bit
Type escape sequence to abort.
Sending 5, 1600-byte ICMP Echos to 192.168.12.2, timeout is 2 seconds:
Packet sent with the DF bit set
.....
Success rate is 0 percent (0/5)
```

```
!-- 在SW2的 f0/13 口可以看到失败的包(5 giants)

SW2#sh int f0/13 | in (MTU|giants|packets )

MTU 1550 bytes, BW 100000 Kbit, DLY 100 usec,

82 packets input, 23609 bytes, 0 no buffer

0 runts, 5 giants, 0 throttles

0 input packets with dribble condition detected

749 packets output, 64729 bytes, 0 underruns
```

华为

S1700, 2700, 5700, CE系列

二层接口MTU

命令支持Ethernet接口视图、GE接口视图、XGE接口视图、MultiGE接口视图、40GE接口视图、端口组视图、Eth-Trunk接口视图

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] jumboframe enable 5000
```

三层MTU

```
[HUAWEI] interface Vlanif 100
[HUAWEI-Vlanif100] mtu 1600
```

```
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] undo portswitch
[HUAWEI-GigabitEthernet0/0/1] mtu 1600
```

某些设备需要重启接口生效: [HUAWEI-GigabitEthernet0/0/1] restart

华三

\$6300, \$5800, \$7500, \$10500, \$5120

二层接口MTU

```
interface G1/1
jumboframe enable 6000

! 聚合组配置 Jumbo Frame
interface Bridge-Aggregation1
jumboframe enable 6000
```

三层MTU

```
[H3C] interface Vlanif 100
[H3C-Vlanif100] mtu 1600
```

在某些软件版本下, 需要使用 ip mtu 1600 命令来调整

锐捷

S8610

version11

三层接口MTU

```
interface interface AggregatePort 10
no switchport
mtu 9216
```

检查

```
show interface agg 10

AggregatePort 10 is UP , line protocol is UP

Hardware is AggregateLink AggregatePort, address is 1414.4b82.25e1 (bia 1414.4b82.25e1)

Description: Link-To-Gold3_HR_VmWare

Interface address is: 172.16.1.1/24

ARP type: ARPA, ARP Timeout: 3600 seconds

Interface IPv6 address is:

No IPv6 address

MTU 9216 bytes, BW 20000000 Kbit
```