

GLOBAL LEADER IN FLEET MANAGEMENT SOLUTIONS



FASTrax Company Vehicles Manual

Information Technology Department

Contents

Getting Started	5
Opening the System	5
Configure Connection Settings	5
Fastrax CV Main Window	6
Configure Connection Settings	6
Logout from the system	7
Exit System	7
Main Menu	8
Navigating Main Menu	8
Global Settings	10
Open Global Settings Option	10
Site Information	10
Modify Site Information	10
Workstation	11
Workstation - Set Automatic Backup	11
Workstation – Set Application Theme	11
Workstation - Set Auto-System Lock	
Backup Database	12
Restore Database	12
User Management	13
Open User Management Option	13
Create New User Account	14
Edit User Account	14
Delete User Account	
Picklist Maintenance - Standard Entries	15
Open Picklist Maintenance Module	
Create a Non-Vehicle Sub Types	16
Edit a Non-Vehicle Sub Types	
Delete a Non-Vehicle Sub Types	
Employee Management	17
Open Employee Management – Manager List	
Create an Employee Profile - Manager	17
Edit an Employee Profile - Local	18
Delete an Employee Profile - Local	18


Dealers	19
Open Dealers Module	
Create a Dealers Information	19
Edit a Dealers Information	21
Delete a Dealers Information	21
Fleet Maintenance Module	22
How to open Fleet Maintenance Module	22
Vehicle Information	23
Create a Vehicle Information	23
Edit a Vehicle Information	26
Delete a Vehicle Information	26
Work Request	27
Create a Work Request	27
Edit Work Request	28
Delete Work Request	28
Work Order	28
Create Work Order	28
Edit Work Order	30
Work Order Details	30
To Issue Work Order Services	30
To Add (Internal) Mechanic to the Work Order	31
To Add (External) Mechanic to the Work Order	31
To Add (Internal) Parts to the Work Order	32
To Add (External) Parts to the Work Order	32
To Close Work Order Transaction	33
Inspection Transaction	33
Create an Inspection Transaction	33
Edit an Inspection Transaction	34
Delete an Inspection Transaction	34
Parts Module	35
Open Parts Module	35
Parts Information	36
Create a Part Information	36
Edit Part Information	37
Delete Part Information	37

Parts Adjustment	38
Parts Adjustment Transaction	38

Getting Started

Opening the System

- 1. Find the Fastrax CV.exe application on the desktop
- 2. Fastrax CV Login window



- 3. Insert the Username and Password
- 4. (Optional) Select System Theme and Color




5. Then click **Login**

Configure Connection Settings

- 1. Click **Connection Settings** on the login window
- 2. Insert the required details: Server Name, Database Name, Server Username, Database Password
- 3. Then click **Test Connection**, a message box will appear if connection is correct/incorrect


Fastrax CV Main Window



- 1. Main Menu Ribbon consist of menu option : File, Edit, Tools, Reports, Help, Lock option, Logout option, Exit option and Global Settings Module
- 2. Main Modules consist of Dealers, Fleet Maintenance, Sales and Parts
- 3. Site Name displays the site name and location
- 4. Status Bar displays the connection property (database connection and database name), logged user, FASTrax CV Version and keylock status(CAPS, NUM, SCROLL)

Configure Connection Settings

- 1. Open the Main Menu then select Lock
- 2. System Lock window will appear, Insert the **password** of the user who locked the system
- 3. Then click **OK**



Logout from the system


1. Open the Main Menu, then select **Logout**

Exit System


1. Open the Main Menu, then select **Exit**

Main Menu


Navigating Main Menu




2. Main Menu




- 3. Global Settings Option
- 4. Exit Option
- 5. Lock Option
- 6. Logout Option
- 7. File Menu




8. Edit Menu




9. Tools Menu



10. Reports Menu




11. Help Menu



Global Settings

Open Global Settings Option


- 1. Open the Main Menu then go to Global Settings
- 2. Global Settings window



Site Information

Modify Site Information

- Select to set the Site Code and system Currency
- 2. Then insert other required information: Site Location, Site Name, Site Email, Contact No, Fax No, and Site Address
- 3. Click the picture ox to change company logo



4. Then click **Save** to modify system site information

Workstation

Workstation - Set Automatic Backup


- 1. Open the Global Settings Option then select Workstation tab
- 2. Set the Backup Path by clicking folder location of the backup file
- 3. Then set the backup time, system accepts twice(2) auto-backup per day.
- 4. Click the checkbox and insert the time



5. Then click Save to set automatic backup

Workstation – Set Application Theme

- 1. Open the Global Settings Option then select Workstation tab
- 2. Select the **Theme** from the listbox



3. Then select the **Theme Color** from the color picker



4. Then click **Save** to set application theme

Workstation - Set Auto-System Lock

- 1. Open the Global Settings Option then select Workstation tab
- 2. Click the checkbox and insert the idle time (minutes) before system lock
- 3. Then click **Save** to set the auto-system lock

Backup Database


- 1. Open the Main Menu then go to File Menu and select Backup Database
- 2. Backup Database window



- 3. Select the type of backup: Full Backup or Reduced Backup
- 4. Click Include Log Activity (available for Full Backup only)
- 5. Then click **Backup** to proceed
- 6. A dialog box will open, choose the folder location of the backup database and then click Save

Restore Database

- 1. Open the Main Menu then go to File Menu and select Restore Database
- 2. Restore Database window




- 3. Click the folder button [22], a dialog box will open to browse the database file to restore
- 4. Select the file and click **Open** and then click **Restore**
- 5. Confirm the restoration by clicking **Yes**
- 6. Once finished the system automatically restarts

User Management

Open User Management Option

- 1. Open the Main Menu then go Tools > User Management
- 2. User Management window



3. Use the following option for **New**, **Edit**, **Delete** users




4. Enter keywords on the search box to find specific user account



Create New User Account

- 1. Open the User Management Module, go to Main Menu > Tools > User Management
- 2. Click New
- 3. **New System User** window will appear



- 4. Insert the required fields: First Name, Last Name, Department, Position, User ID, Password
- 5. Select the Privilege assign to the new user. Click each check box desired

Edit User Account

- 1. Open the User Management Module, go to **Main Menu** > **Tools** > **User Management**
- 2. Select the user from the list then click **Edit**
- 3. **Modify System User** window will appear
- 4. Insert the additional/modified information
- 5. On the privilege section, check/unchecked the privileges assign to the user
- 6. Once all desired information are added/edited click Save


Delete User Account

- 1. Open the User Management Module, go to Main Menu > Tools > User Management
- 2. Select the user from the list then click **Delete**
- 3. A message box will appear and confirm the deletion by clicking **Yes**

Picklist Maintenance - Standard Entries

Open Picklist Maintenance Module

- 1. Open the Main Menu then go Edit > Fleet Picklist > Non-Vehicle Sub Types
- 2. Picklist Maintenance window



The sample image is a Non-Vehicle Sub Types Picklist Maintenance

3. Use the following option for **New**, **Edit**, **Delete** standard entries



4. Enter keywords on the search box to find specific standard entries




List of Standard Entries in the Picklist Maintenance Module

Non-Vehicle Sub Types, Additional Charges, Common Damage Information, Department Types, Employee Positions, Employee Skill Levels, Packing List Receivers, Parts Categories, Parts Vehicle Types, Parts Location, Province, Repair Groups, Vehicle Type, Vehicle Ownership, Unit of Measurements, Vehicle Colors, Vehicle Makes, Vehicle Models, Vehicle Series, Currency, Repair Type

Create a Non-Vehicle Sub Types

- 1. Open the Main Menu then go Edit > Fleet Picklist > Non-Vehicle Sub Types
- 2. Then click New
- 3. New Non-Vehicle Sub Type window



- 4. Insert the required information : Sub Code, Sub Type, Next No
- 5. Once all information are inserted, click **Save**

Edit a Non-Vehicle Sub Types

- 1. Open the Main Menu then go Edit > Fleet Picklist > Non-Vehicle Sub Types
- 2. Select the Non-Vehicle Sub Types from the list then click Edit
- 3. Modify Non-Vehicle Sub Type window will appear
- 4. Insert the additional/modified information
- 5. Once all desired information are added/edited click **Save**


Delete a Non-Vehicle Sub Types

- 1. Open the Main Menu then go Edit > Fleet Picklist > Non-Vehicle Sub Types
- 2. Select the Non-Vehicle Sub Types from the list then click **Delete**
- 3. A message box will appear and confirm the deletion by clicking **Yes**

Employee Management


Open Employee Management – Manager List

- 1. Open the Main Menu then go Edit > Employee Picklist > Manager
- 2. Employee Management Manager window




Create an Employee Profile - Manager

- 1. Open the Main Menu then go Edit > Employee Picklist > Manager
- 2. On Employee Management Manager window, click New
- 3. New Manager Employee window



4. Insert the required information



- Set Employee Manager status to active/inactive
- 5. Once all information are inserted click Save

Edit an Employee Profile - Local

- 1. Open the Main Menu then go Edit > Employee Picklist > Local
- 2. On Employee Management Local window, select employee from the list and click Edit
- 3. **Modify Local Employee** window opens, Insert the additional/modified information
- 4. Once all desired information are added/edited click Save

Delete an Employee Profile - Local

- 1. Open the Main Menu then go Edit > Employee Picklist > Local
- 2. On Employee Management Manager window, select employee from the list and click Delete
- 3. A message box will appear and confirm the deletion by clicking **Yes**

Dealers

Open Dealers Module


1. On the FASTrax CV Main window, go to the Main Modules tab and select **Dealers**



- 2. Ribbon menu Options for Add, Edit, Delete, Refresh, Filter, Print dealer information
- 3. FASTrax CV Dealers Tree Menu: Dealer Data
- 4. Dealer list

Create a Dealers Information


- 1. Go to **Dealers Module** then select **Dealers Information** > **Dealers Data** from the sidebar
- 2. Then click **Add** from ribbon menu
- 3. **New Dealer** window will open




4. Insert the required information



5. **Provided Vehicle** tab - list all the vehicles provided by the Dealer




6. **Attachments** tab - Add, Insert, Delete attachments(documents, contracts, images, policy, etc.) to the Dealer's information



Click to browse the file to be attached then insert the **Description** and click **OK**

7. **Others** tab - custom fields can be inserted using the UDF and additional Notes



8. Once all information are inserted click Save

Edit a Dealers Information

- 1. Go to **Dealers Module** then select **Dealers Information** > **Dealers Data** from the sidebar
- 2. Select the Dealer from the list then click **Edit** from ribbon menu



- 3. Modify Dealer window will appear
- 4. Insert the additional/modified information : Data, Attachments Information
- 5. Once all desired information are added/edited click Save

Delete a Dealers Information

- 1. Go to **Dealers Module** then select **Dealers Information** > **Dealers Data** from the sidebar
- 2. Select the Dealer from the list then click **Delete** from ribbon menu




3. A message box will appear and confirm the deletion by clicking Yes

Fleet Maintenance Module

How to open Fleet Maintenance Module

1. On the FASTrax CV Main window, go to the Main Modules tab and select Fleet Maintenance



2. Ribbon menu - Options for Add, Edit, Delete, Refresh, Filter, Print Vehicle information


Filter and Search Options - a multifunction filter option, select the desired status or maintenance cycle



Work Request, Work Order and Inspection Option - select the vehicle and click desired transaction to create



History, Disposition Management Options - select the vehicle from the list to view vehicle history or open the Disposition Management window



Show Hide Form Option - select the vehicle from the list and a sidebar form for Vehicle Information will appear.



Generate XML File Option select the vehicle from the list and click the option to generate and export a vehicle information. This option is used mostly for vehicle transfer




- 3. FASTrax CV Fleet Maintenance Tree Menu: Fleet Maintenance
- 4. Vehicle Inventory List

Vehicle Information

Create a Vehicle Information

- 1. Go to **Fleet Maintenance** Module then select **Fleet Maintenance** > **Vehicle Inventory** from the sidebar
- 2. Then click Add from ribbon menu
- 3. New Vehicle Information window will open




4. Insert the required information

- Required text box


Exclude from Inspection - enable this option and the vehicle will be excluded for creating Inspection transaction

5. **Armor** tab




Armored - if a vehicle is armored check the option, then insert the desired armor details

6. Images tab – Option available to Add, Edit, Delete, Vehicle Images



To Insert Image

- Click New to open an Image dialog box, click the image area to browse and insert the image.




- Insert the the description then click Save

To Edit Image

- From the Images tab, Click the description from the list and click **Edit**
- Then on the Image dialog box, click the image area to open file browser and select the image
- Change the description then click Save

To Delete Image

- From the Images tab, Click the description from the list and click **Delete** then confirm the deletion
- 7. **Others** tab Insert additional user defined fields, notes and manage Document attachments




To create user defined field

- From the Others tab, click the label to change the name



- Insert the field name and click OK



To Manage Document Attachments

- From the **Others** tab, go to Attachments section and click **Add**
- A dialog box will open, browse the document then click **Open**




To Manage Document Attachments

- From the **Others** tab, go to Attachments section and click **Add**
- A dialog box will open, browse the document then click **Open**
- 8. Once all information are inserted click **Save**

Edit a Vehicle Information

- 1. Go to Fleet Maintenance Module then select Vehicle Inventory > Vehicle from the sidebar
- 2. Select the Vehicle from the list then click **Edit** from ribbon menu



- 3. **Edit Vehicle Information** window will appear
- 4. Insert the additional/modified information
- 5. Once all desired information are added/edited click Save


Delete a Vehicle Information

- 1. Go to Fleet Maintenance Module then select Vehicle Inventory > Vehicle from the sidebar
- 2. Select the Vehicle from the list then click **Delete** from ribbon menu
- 3. A message box will appear and confirm the deletion by clicking Yes


Work Request

Create a Work Request

1. Go to **Fleet Maintenance Module**, select **Fleet Maintenance** > **Vehicle Inventory** from the sidebar then select the vehicle from the list and click **Work Request**



2. New Work Request window



3. Insert the required information (odometer reading, complaint(s))



- Check if the Work request is a 45 Days Inspection
- 4. Click **Save** if all information are inserted

Edit Work Request

- 1. Go to **Sales Module**, select **Sales > Work Request** from the sidebar then select the transaction from the list and click **Edit**
- 2. Update the Work Request information
- 3. To Convert Work Request to a Work Order, click Create WO

Delete Work Request

- 1. Go to **Sales Module**, select **Sales > Work Request** from the sidebar then select the transaction from the list and click **Delete**
- 2. A message box will appear and confirm the deletion by clicking Yes

Work Order

Create Work Order


- 1. Go to **Sales Module**, select **Sales > Work Request** from the sidebar then select the work request transaction and click **Edit**
- 2. On the Work Request window, click the Create WO option
 - see also **Edit Work Request** instruction
- 3. A confirmation will appear and click Yes
- 4. New Work Order window




5. Insert the required information

Odometer - the value should be higher than the previous odometer


Repairs Tab - check the services to be tagged to the Work Request



Service Tab - list of selected items from the Repairs Tab - <u>Issue Services to Work Order</u>




Parts Tab - Insert the parts to be issued to the work order. Parts can be from the inventory. Parts can be from the Inventory(internal) or External



To Add Parts - From the Inventory or External3

Mechanics Tab - Insert the mechanics name and details of the labor cost. Mechanics information can be from the employee list(internal) or External



To Add Mechanic - Internal and External

Others Tab - Insert additional information for the Work Order



6. Click **Save** once all desired information are inserted

Edit Work Order

- 1. Go to **Sales Module**, select **Sales > Work Order > Open** from the sidebar then select the work order transaction and click **Edit**
- 2. Update the Work Order Information. See Work Order Details
- 3. Once all information are inserted click **Save**

Work Order Details

To Issue Work Order Services

- 1. On the Service(s) tab select the service code and click **Issue Service**
- 2. Service Details window




- 3. Insert the **Hours** expected and **Sales Price** for the service
- 4. Click **Issued** check box to add the service to the Work Order

Note: If a service was issued the system requires a mechanic to be tagged to the service details

5. Once all information are inserted click **Save**

To Add (Internal) Mechanic to the Work Order

- 1. On the Mechanic(s) Tab, select the mechanic from the combo box and click **Add**
- 2. Select Service Performed window



- 3. Select the **Service Code** performed and insert the actual **hours** rendered
- 4. Once all information are inserted, click Save

To Add (External) Mechanic to the Work Order

- 1. On the Mechanic(s) Tab, select the ADD NEW item from the combo box and click Add
- 2. On the **Select Service Performed** window, insert the mechanic **name** and **position**
- 3. Select the **Service Code** performed and insert the actual **hours** rendered
- 4. Once all information are inserted, click Save

To Add (Internal) Parts to the Work Order

- 1. On the Parts tab, click **Add** with an empty combo box
- 2. New Part window



- 3. Insert the Requested Qty
- 4. If parts is to be issued already click **Issued** check box and insert **Date closed** and if **Old Part Returned** check the status
- 5. Once all information are inserted, click **Save**


To Add (External) Parts to the Work Order

- 1. On the Parts tab, click **Add** with an empty combo box
- 2. New Part window
- 3. Insert the Part No, Description, Cost Price, Unit Type, Requested Qty
- 4. If parts is to be issued already click **Issued** check box and insert **Date closed** and if **Old Part Returned** check the status
- 5. Once all information are inserted, click **Save**

Note: Once external parts are issued it will automatically be added on the Parts Listing of the system with **non-stocking** status

To Close Work Order Transaction

- 1. Open the Work Order Transaction and check all details if correct
- 2. On the Status box, change **Open** to **Closed**




- 3. Then click Save
- 4. If the Work Order doesn't have an Inspection transaction tagged the system ask to create one but this is an optional method. Click **No** to proceed closing without Inspection


Inspection Transaction

Create an Inspection Transaction


- 1. Go to **Fleet Maintenance Module**, select **Fleet Maintenance** > **Vehicle Inventory** from the sidebar then select the vehicle from the list and click **Inspection**
- 2. New Equipment Inspection window



3. Insert the required information



Tagged the Work Order to Inspection transaction(optional)




Select the items that are non-mission capable then provide the details of the inspection

4. Once all information are inserted click Save

Edit an Inspection Transaction

- 1. Go to Sales Module then select Sales > Vehicle Inspection from the sidebar
- 2. Select the inspection transaction from the list then click **Edit** from ribbon menu




Use the search box to find the Inspection transaction

- 3. Modify Equipment Inspection window will appear
- 4. Insert the additional/modified information
- 5. Once all desired information are added/edited click Save

Delete an Inspection Transaction

- 1. Go to Sales Module then select Sales > Vehicle Inspection from the sidebar
- 2. Select the Inspection transaction from the list then click **Delete** from ribbon menu




Use the search box to find the Inspection transaction

3. A message box will appear and confirm the deletion by clicking Yes

Parts Module

Open Parts Module

1. On the FASTrax CV Main window, go to the Main Modules tab and select **Parts**



2. Ribbon menu - Options for Add, Edit, Delete, Refresh, Filter, Print Parts information

Filter and Search Options - a multifunction filter option, select the desired status or maintenance cycle



- 3. FASTrax CV Parts Tree Menu: Parts Data
- 4. Parts Inventory List

Parts Information

Create a Part Information

- 1. Go to **Parts Module** then select **Parts > Parts Data** from the sidebar
- 2. Then click Add from ribbon menu
- 3. **New Part Information** window



4. Insert required information



- Check item if the parts will be set to inactive

5. **Parts Location** section - Identify the parts location and shelf



- Click **New** to open a dialog box to insert Part Location & Shelf

- 6. Others tab Insert additional user defined fields and notes
- 7. Once all information are inserted click **Save**


Edit Part Information

- 1. Go to **Parts Module**, select **Parts > Parts Data** from the sidebar then select the parts information from the list and click **Edit**
- 2. Update the parts information

View Parts Audit Trail

On the parts information, click Audit Trail tab

Click Go to list down all transaction on the List View



Check **Specify Dates** and select the date range to audit then click **Go**

View Stock Adjustment History

On the parts information, click Stock Adjustment History tab

Click Go to list down all stock adjustment history

Check **Specify Dates** and select the date range to view parts history

3. If all required information are inserted click Save

Delete Part Information

- 1. Go to **Parts Module**, select **Parts > Parts Data** from the sidebar then select the parts from the list and click **Delete**
- 2. A message box will appear and confirm the deletion by clicking Yes


Parts Adjustment

Parts Adjustment Transaction

1. Go to Parts Module then on the ribbon click Parts Adjustment




2. Parts Adjustments window



3. Select the **Location** to populate all parts to list



4. Select the parts to adjust by ticking the check box. Select the new **location**, enter the new **qty** and then **remarks**



5. Once all adjustment for parts are finished, click **Save**