
RMS6 -ERP
(ERP-State)

Article no.:	**MSWR2360**
Date:	**04.01.2016**
Version	**1.07**
Author:	**Röders GmbH**



Roeders GmbH • Scheibenstrasse 6 • D-29614 Soltau (Germany)
Phone +49 5191 603 43 • Fax +49 5191 603 38
E-Mail hsc@roeders.de • Internet www.roeders.de

© Copyright 2016
RÖDERS GmbH
Scheibenstrasse 6
D-29614 Soltau, Germany

röders TEC

1 Contents

1 Contents 3
2 History 4
3 Version state 5
4 File output – ERP State 5
4.1 Time format 5
4.2 Data structure 5
4.2.1 XML-document 6
4.2.2 XML-contents 6
4.2.1 User-specific output fields 8
4.3 File access 9
5 Examples 10

2 History

■ 1.01	Original version, based on TC.0919	D. Wagner
■ 1.02	Layout	D. Wagner
■ 1.03	Versionstate	S. Friedemann
■ 1.04	Expansion <state> and outputs <doorstate>, <autodoorstate> and <lastjobend>	S. Friedemann
■ 1.05	English translation	M.Reinecke
■ 1.06	Expansion BDE output	S. Friedemann
■ 1.07	Divided into interface and setup documentation	S. Dailidow

3 Version state

- Generating ERP state

  Since RMS6 version: 3.50 (196)

  3.60 (207)

- Creation of additional outputs concerning state of doors (manuel and automatic) and time of last processing

  Since RMS6 version: 4.61 (246) and 4.62 (125)

- Differentiation of machinestate „IDLE“ regarding ‘machine OUT’ or ‘machine ECO Mode[1]‘

  Since RMS6 version: 4.61 (246) and 4.62 (125)

- Option: additional output of operation datat (Machine.bde, c_MDC, s4ERPStateOption=&2))

  Since RMS6 version: 5.51 (236)

4 File output – ERP State

If the RMS6-control is active, machine state is outputted. In order to do so an XML-file is updated cyclical.

4.1 Time format

- Time format has to be *YYYY-MM-DD HH:MM:SS*[2].

  Example: 2010-02-23 09:27:55

- Time counter in seconds

4.2 Data structure

The parts of *xml*-file beeing used for the data output and their meaning is going to be explained in the following.

[1] Additional configuration of the RMS6 is necessary
[2] time disclosures: Y = year; M = month; D = day; H = hour; M = minute; S = second

4.2.1 XML-document

- All names of elements are in lowercase and can contain a text content, for empty elements you can use the abbreviated notation.

  The elements are free of attributs.

  The root-element is called <*erp*> and is above an ERP-output block.
- Encoding is done according to ISO-8859-1

4.2.2 XML-contents

- The table includes names of elements,their usage, and also the used output formats.

Element	Usage	Data type
<erp>	Root-elelement, is ahead of an ERP-output block	-
<version>	Version of output format	Float

<data>	xml-block for data	
<time>	Timestamp	Time format: YYYY-MM-DD HH:MM:SS
<name>	Machine name	Text
<ver>	Version of RMS6-controlsoftware	Text
<mode>	Mode **MANUAL, AUTOMATIC**	Text
<state>[3]	State of machine **IDLE, OFF, ECO, RUNNING, ERROR**	Text

[3] The states „OFF“ and „ECO“ are optional (additional RMS6 configuration is necessary, since RMS6 4.61 (246) or 4.62 (125))

<doorstate>[4]	State of manuel machine doors	Text
	CLOSED, OPEN	
<autodoorstate>[4]	State of automatic doors	Text
	CLOSED, OPEN	

<feed>	Feed (mm/min)	Float
<ov_feed>	Override feed (in percent)	Float
<tool>	Locationnumber of actual tool	Integer
<tooltype>	Spindel tooltype	Text
<spinspeed>	Spindle speed (rpm)	Float
<ov_spinspeed>	Override spindle speed (in percent)	Float

<job>	xml-block for actual job(only during a job is running)	
<name>	Current job	Text
<ncpgm>	Path of chosen NC-file	Text
<start>	Time of jobstart	Time format: YYYY-MM-DD HH:MM:SS
<lastjobend>[5]	Time of completing last job	Time format: YYYY-MM-DD HH:MM:SS
<subpgm>	Path of the actual subprogram	Text
<substart>	Time of beginning subprogram	Time format: YYYY-MM-DD HH:MM:SS
<percent>	Progress (in percent)	Float
<line>	Current program line	Integer
<chuck>	Current Chuck	Integer
<pallet>	Current pallet	Integer
</job>	End of xml-block *job*	

<user>	xml-block, user-specific data, see chapter 5.2.1	
</user>	End xml-block *user*	

[4] The element is available since RMS6 4.61 (246) or 4.62 (125)
[5] Element is available since RMS6 4.61 (246) or 4.62 (125)

<bde>	xml-Block for operating data	
<bde_start>	Start of operating data collecting	Time format: JJJJ-MM-TT HH:MM:SS
<op_duration>	Operating time	Time in seconds
<op_percent>	Operating utilization in percent	Text
<nc_duration>	Milling time	Time in seconds
<nc_percent>	Milling utilization in percent	Text
<set_duration>	Rüstzeit	Time in seconds
<set_percent>	Setup time utilization in percent	Text
<spin_start>	Start of spindle data collecting	Time format: JJJJ-MM-TT HH:MM:SS
<spin_duration>	Spindle on time	Time in seconds
</bde>	End xml-Block *bde*	

</data>	End xml-block *data*	
</erp>	End xml-block *erp*	

4.2.1 User-specific output fields

- By NC-command *ERPSTATE* with the options *–N*, *–NUM* / *-T* you can get an userspecific output while the program is in process.

  Opening processing dialog will delete the whole content of user specific output. By specifying the same name with an empty text in output the entry for this name will be erased.

Element	Usage	Data type
<user>	xml-block for user-specific data	
<?>		
</user>	End xml-block *user*	

Syntax

ERPSTATE *-N*= [*-T*= or *-Num*=]

Options:

-N=	Sets name for output.
-T=	Sets text for output.
-Num=	Sets value for output.

4.3 File access

The output file will be updated automaticlly if data has been changed. Updating is done (*s2ERPRefreshFile*) in seconds.

Requests to the file must be selected, the file has to be released in RMS6-settings (0.5**s2ERPRefreshFile*), otherwise an error message will appear.

If the filepath is not valid an error message will appear.

5 Examples

- Machine in idle state

Example: ERP-State (state.xml)

```
<?xml version="1.0" encoding="iso-8859-1"?>

<erp>
   <version>1.0</version>
   <data>
      <time>2008-03-05 10:44:53</time>
      <name>RXP500_Test</name>
      <ver>3.41 (212)</ver>
      <mode>MANUAL</mode>
      <state>IDLE</state>
      <feed>0</feed>
      <ov_feed>100</ov_feed>
      <tool />
      <tooltype />
      <spinspeed>0</spinspeed>
      <ov_spinspeed>100</ov_spinspeed>
      <job>
         <ncpgm>f:\public\pro\testup\hp.bef</ncpgm>
      </job>
      <user />
   </data>
</erp>
```

- Machine with running job

Example: ERP-State (state.xml)

```
<?xml version="1.0" encoding="iso-8859-1"?>

<erp>
   <version>1.0</version>
   <data>
      <time>2008-03-05 10:44:53</time>
      <name>RXP500_Test</name>
      <ver>3.41 (212)</ver>
      <mode>MANUAL</mode>
      <state>RUNNING</state>
      <feed>2500</feed>
      <ov_feed>100</ov_feed>
      <tool>3</tool>
      <tooltype>Typ1</tooltype>
      <spinspeed>3000</spinspeed>
      <ov_spinspeed>100</ov_spinspeed>
      <job>
         <name />
         <ncpgm>f:\public\pro\testup\hp.bef</ncpgm>
         <start>2008-02-06 10:08:43</start>
         <subpgm>f:\public\pro\testup\up.bef</subpgm>
         <substart>2008-02-06 10:09:14</substart>
         <percent>4</percent>
         <line>10</line>
         <chuck />
         <pallet />
      </job>
      <user />
   </data>
</erp>
```

- Machine with running job and user output

Example: ERP-State (state.xml)

```
<?xml version="1.0" encoding="iso-8859-1"?>

<erp>
   <version>1.0</version>
   <data>
      <time>2009-01-29 07:53:07</time>
      <name>RXP500_Test</name>
      <ver>3.60 (260)</ver>
      <mode>MANUAL</mode>
      <state>RUNNING</state>
      <feed>2500</feed>
      <ov_feed>100</ov_feed>
      <tool>1</tool>
      <tooltype>Typ1</tooltype>
      <spinspeed>5000</spinspeed>
      <ov_spinspeed>100</ov_spinspeed>
      <job>
         <name />
         <ncpgm>D:\test1.bef</ncpgm>
         <start>2009-01-29 07:52:28</start>
         <percent>9%</percent>
         <line>8</line>
         <chuck />
         <pallet />
      </job>
      <user>
         <text1>2233475748.0000</text1>
         <text2>AUFTRAG 5</text2>
      </user>
   </data>
</erp>
```

- Syntax for an example of user output

Example: Textexcerpt NC-program

```
ERPSTATE -NUM=2233475748 -N="text1"
…
ERPSTATE -T="Order 4711" -N="text2"
...
ERPSTATE -T="" -N=text1  // would delete entry text1
```