



ID CARD

User Guide & FAQs

Table of Contents

Table of Contents	2
Introduction	3
Three Essential Rules.....	3
Do's and Don'ts	3
What Your Card Does	4
Card Specifications	4
Wearing Your Card	4
Charging Your Card	5
Before You Charge	5
Charging Steps	5
Battery Life	5
Understanding the LED	6
If Something Goes Wrong	6
Step 1 — Check the LED	6
Step 2 — Charge the Card	6
Lost or Damaged Card	6
Safety Information.....	7
Frequently Asked Questions	8
General	8
Charging and Battery.....	8
Daily Use.....	8
Safety	9

Introduction

The WakeCap Rechargeable ID Card is a credit-card-sized wireless device worn by workers on construction and oil & gas sites. It automatically tracks their location, records attendance (time in/out), and detects potential falls — all without any interaction from the wearer. Each card is assigned to one worker, printed with their photo and details using a UV printer, and recharged monthly via USB. It communicates through WakeCap's mesh network of Anchors and Gateways, feeding real-time data to the Portal where supervisors monitor site activity and safety events.

Three Essential Rules

1. **Wear your card** at all times while on-site — on a lanyard or clipped to your clothing.
2. **Charge it monthly** — plug in the USB cable, wait for a full charge, unplug.
3. **Report problems** to your supervisor — if your card isn't working, don't ignore it.

Do's and Don'ts

Do	Don't
Wear the card visibly on a lanyard or clip	Don't store the card in a metal box, locker, or tool case
Charge your card once a month	Don't wait until the card is completely dead
Report a lost or damaged card immediately	Don't try to open, bend, or modify the card
Keep the card dry and away from extreme heat	Don't share or swap your card with another worker

What Your Card Does

The WakeCap Rechargeable ID Card is a wireless safety and attendance card assigned to you. Once charged and activated, it works automatically — you do not need to press any buttons or open any apps.

Your card tracks:

- Your **location** on the project site (which zone you are in)
- Your **attendance** (time in, time out, total time on-site)
- **Safety events** such as potential falls (free fall detection)

Card Specifications

Parameter	Value
Size	86 x 55 x 6 mm (credit card width and height, slightly thicker)
Weight	75g ±5g
Color	White (all sides)
Battery	Rechargeable lithium polymer, 365 mAh
Charging	USB cable (included)

Wearing Your Card

Wear the card **at all times** while you are on the project site.

Recommended wearing methods:

- **Lanyard** — hang the card around your neck, with the printed side facing outward.
- **Card holder clip** — attach the clip to your clothing at chest or waist level.

NOTICE

Do not share or swap your card with another worker. Each card is linked to the assigned person, sharing it causes incorrect attendance records and unreliable safety alerts for both workers.

Charging Your Card

Charge your card **once a month**. Make it a routine — for example, charge on the first working day of each month so you never run out of battery mid-shift.

⚠ NOTICE

Do not wait until the card is completely dead. A fully discharged card takes longer to come back online and may miss attendance records until it reconnects.

Before You Charge

⚠ WARNING

Ensure your hands are dry before handling the USB cable and charger. Do not charge the card near water, wet surfaces, or in damp environments. Inspect the card for cracks, swelling, or visible battery bulge — do not charge a damaged card. Use only the provided USB cable or a compatible replacement. Do not use frayed, damaged, or exposed cables.

Charging Steps

1. Connect the USB charging cable to the port on the bottom edge of the card.
2. Plug the other end into any USB power source — a wall adapter, computer USB port, or USB hub.
3. Check the LED indicator — Green led blinks means charging in progress, Green led solid means fully charged.
4. Disconnect the cable when charging is complete. Do not leave the card connected to the charger indefinitely.

⚠ NOTICE

Do not charge cards in direct sunlight, near heaters, or in environments above 60 °C. Excessive heat reduces battery lifespan and may damage the card.

Battery Life

How long a single charge lasts depends on the card's configuration:

Configuration	Battery Life Per Charge
Standard (30-second updates)	Approximately 1 month
Extended (3-minute updates)	Approximately 3 months

Most sites use the **standard configuration** with a monthly recharge cycle.

Understanding the LED

The small LED on your card indicates the card's status. During normal daily use, the LED is off — this is normal, the card is working in the background.

What You See	What It Means	What to Do
Green LED – Blink (once)	Card is ON and working fine	Nothing
Green LED - Blinks	Card is charging	Leave it connected until fully charged
Green LED - Solid	Card is fully charged	Disconnect the cable
Red LED - Blinks	Battery is low	Needs charging, best to charge now
No response when you press the power button	Battery is completely dead	Charge for at least 30 minutes, then try again

If Something Goes Wrong

Follow these steps in order. Stop as soon as the issue is resolved.

Step 1 — Check the LED

Press the power button on the card. Do you see a green led blink once?

- **Yes** — The card has power & is working fine
- **No** — See red led --> battery low, charge the Id card
- **No** — No led activity --> The battery is dead. Go to Step 2.

Step 2 — Charge the Card

Connect the card to a USB charger for at least **30 minutes**. Then press the power button again.

- **Green LED blinks** — it was discharged, its working fine now
- **Still no response** — The card may be defective. Report it to your supervisor for replacement.

Lost or Damaged Card

Situation	Action
Card lost	Report to your supervisor immediately. They will deactivate the card and issue a replacement.
Card cracked, bent, or swollen	Stop using it. Do not charge it. Hand it to your supervisor for safe disposal and replacement.
Card dropped in water	Remove it from water, dry it off, and report to your supervisor. Do not attempt to charge a wet card.

Safety Information

WARNING

Do not attempt to open the card housing. The card contains a sealed lithium polymer battery that is not user-serviceable. Opening the card may cause battery damage, swelling, or fire.

CAUTION

Do not puncture, crush, bend excessively, or expose the card to extreme heat (above 60 C). Damaged batteries may swell, leak, or ignite.

NOTICE

Dispose of damaged or end-of-life cards through your site's electronic waste disposal process. Do not discard in general waste. The card contains a lithium battery that must be handled according to local regulations.

Frequently Asked Questions

General

What is the WakeCap ID Card?

A rechargeable wireless card that automatically records your presence on-site, tracks which zones you enter, and can detect potential fall incidents. It works without any action from you, just wear it.

Do I need to press any buttons or open any apps?

No. The card works automatically once charged and configured. You do not interact with it during normal use.

Is my personal information stored on the card?

Your personal information (name, employee details) is stored securely on the WakeCap Portal. The card itself only stores a device ID used by the system.

My attendance record shows I was absent but I was on-site all day — what happened?

Contact administrator.

How do I know my card is actually working during the day?

Click the button, if the Green LED blinks, then it's working.

Charging and Battery

How often do I need to charge?

Once a month. Pick a fixed day each month and make it a habit.

How long does a full charge take?

Leave the card connected until the Green LED is solid ON, this indicates a full charge.

What happens if my card battery dies?

Your attendance will not be recorded and safety monitoring will pause for your card. Charge the card as soon as possible.

Can I use any USB cable?

Use the provided cable or a compatible USB cable that fits the card's port. Do not force a connector that does not match.

The card feels warm while charging. Is that normal?

Slight warmth is normal. If the card becomes hot to the touch, disconnect it immediately, move it away from heat sources, and report it to your supervisor.

Daily Use

Is the card waterproof?

The card is designed for outdoor construction environments and can handle light rain and dust. Avoid submerging it in water.

Can I put stickers on the card or write on it?

Do not cover the center area or the LED indicator. Your employee details are printed by the site team using a specialized printer.

What should I do if I lose my card?

Report the loss to your supervisor immediately. They will deactivate the lost card and issue you a replacement.

What should I do if my card is cracked, bent, or swollen?

Stop using it immediately and do not attempt to charge it. Hand it to your supervisor for safe disposal.

I see multiple detections in a short time on my record. Is this normal?

Occasional rapid detections can happen at zone boundaries. If it occurs frequently, report it to your supervisor.

Safety

Does the card detect falls?

Yes. The card has a built-in fall detection sensor. Because the card hangs on a lanyard, it may occasionally trigger false alerts when the card swings sharply or is dropped. Report any false alerts to your supervisor.

How do I dispose of a card that no longer works?

Do not throw it in general waste. The card contains a lithium polymer battery and must be disposed of through your site's electronic waste process.

-----END of DOCUMENT-----