

The keys



- White 1–8** pads of bank **A** (or **C**)
- White 9–16** pads of bank **B** (or **D**)
- OCT+** **OCT–** banks **C + D** / back to **A + B** (the LEDs A–D show which)
- black keys** **loops 1–11**: stopped at once; playing: from the end of the loop (its key blinks, the LCD says **LOOP 3 NEXT**). The loop playing is lit.
- ARP** **MULTI PITCH**: the last sound on all 27 keys, F4 (white 8) as tuned. ARP again: pads.
- USB MIDI** notes 36–67 play pads A1–D8

The factory sounds

A1 KICK	A2 SNARE	A3 RIM	A4 CLAP	A5 HAT	A6 OHAT	A7 TOM L	A8 TOM H
B1 CRASH	B2 RIDE	B3 COWBL	B4 TAMB	B5 SHAKR	B6 CONGA	B7 CLAVE	B8 WOOD
C1–C8 bank A	bank A lower, 45 → 33, the filter on ch 1–2						
D1 EP Dm9	D2 EP Gm9	D3 HORNS	D4 VIBES	D5 BASS	D6 SCRCH	D7 SPIN	D8 SNAP

Any pad, any of these 24 samples: **EDIT** → WAVE, KNOB 1. 12 bit at 26.04 kHz, pitched without interpolation.

Sound

- Channels** a pad plays on a channel 1–8 (OUT, CHAN); one sound at a time each: a new hit cuts the last (HAT and OHAT share 3)
- 1–2** a 4-pole resonant low-pass whose cutoff follows the decay (CUT, RESO)
- 3–6 · 7–8** a fixed low-pass · no filter
- 45 → 33** TRUNC, SPEED: played at 33/45 of its rate: lower, grainier

The knobs

- | | |
|------------------------|------------|
| A1 KICK | 090 |
| CH1 CH2 CH3 CH4 | |
| 100 100 100 100 | |
- KNOB 1–4** the **faders** of channels 1–4; **SEL** held: **5–8**. The LCD's four columns always say what the knobs do.
- A page** EDIT, FX, SEQ, GLO open one; untouched for **6 s**, or **HOME**: the faders again
- SELECT** tempo
- ALGORITHM** the sound to edit (A1 ... D8), without playing it
- PRESETS** **the sample** of the pad you hit last: one sample on as many pads as you like, each with its own TUNE, DECAY ...
- MASTER** the volume

Pages · KNOB 1 · 2 · 3 · 4

- EDIT** **WAVE** the pad's sample · COPY> pad · COPY (turn twice) · –
- SOUND** TUNE (semitones) · FINE · DECAY · LEVEL
- TRUNC** START · END · DIR (fwd / rev) · SPEED (45 / 33)
- OUT** CHAN · PAN · CUT · RESO (CUT / RESO on ch 1–2)
- SENDS** DRIVE · CHO · DLY · REV: **the effects of this pad**
- FX** **CHORUS** RATE · DEPTH · MIX
- DELAY** TIME (1/4 ... 16T, in tempo) · FDBK · COLOR · MIX
- REVERB** SIZE · DAMP · PRE (ms)
- SEQ** **LOOP** LOOP · BARS (AUTO, 1–32) · QUANT (AUTO CORRECT) · SWING 50–71 %
- LOOP TOOLS** CLEAR (turn twice) · COPY> loop · COPY (turn twice)
- SONG** STEP · LOOP · REPEAT (0: the song ends here) · SONG OFF / 1–4
- GLO** **SETUP** TEMPO · CLICK (off / rec / on) · VER · RESET (turn twice: the factory state)
- Each tap of EDIT, FX or SEQ: the next of its pages.

Make a beat

- REC** (it blinks: armed), **PLAY**: a bar of count-in.
- Play kick and snare. **AUTO CORRECT** puts them on the grid.
- REC** again at the end: an empty loop (BARS **AUTO**) is now as long as your take.
- Hats step by step: hit the hat, **hold SEQ**: the white keys are its 16 steps (lit = a hit), tap to set / clear; **OCT+** the next bar.
- REC** while it plays: overdub more on top; **REC** again: off.
- Turn TUNE, DECAY (EDIT → SOUND) or CUT while recording: **the pad's hits keep what you turned** (a red dot in the step grid).
- A chord: **OCT+**, white 9 (D1). Melodic: **ARP** (MULTI PITCH).
- Another loop: a black key, record into it. Songs: SEQ → SONG.

Buttons

- PLAY** run / stop (lit while it runs)
- REC** stopped: armed (blinks); playing: overdub on / off; **hold 2 s**: clear the loop
- EDIT** + **OCT–** **undo** the last clear / erase / copy (again: redo)
- LFO** + **pad** **erase**: that pad's hits go as the playhead passes (stopped: all at once)
- ENV** tap tempo (it blinks on the beat)
- SAVE** save now; **held + a black key**: the loop into that loop; stopped and quiet for 3 s it saves by itself
- HOME** the faders

Effects in 3 steps

- Hit the pad (the snare).
- EDIT** until the LCD says **SENDS**.
- KNOB 4 = REV, KNOB 3 = DLY. Shape them: **FX**.

Back to sloopDX: its installer. No answer? Hold OCT– while switching on (USB rescue).