


The keys



White 1–8 pads of bank **A** (or **C**)

White 9–16 pads of bank **B** (or **D**)

OCT+ **OCT–** banks **C + D** / back to **A + B** (the LEDs A–D show which)

black keys **loops 1–11**: stopped at once; playing: from the end of the loop (its key blinks, the LCD says **LOOP 3 NEXT**). The loop playing is lit.

ARP **MULTI PITCH**: the last sound on all 27 keys, F4 (white 8) as tuned. ARP again: pads.

USB MIDI notes 36–67 play pads A1–D8

The factory sounds

A1 KICK	A2 SNARE	A3 RIM	A4 CLAP	A5 HAT	A6 OHAT	A7 TOM L	A8 TOM H
B1 CRASH	B2 RIDE	B3 COWBL	B4 TAMB	B5 SHAKR	B6 CONGA	B7 CLAVE	B8 WOOD
C1–C5 A1–A5	bank A lower, 45 → 33, the filter on ch 1–2				C6 PNO Cm9	C7 PNO F13	C8 PIANO
D1 EP Dm9	D2 EP Gm9	D3 HORNS	D4 VIBES	D5 BASS	D6 SCRCH	D7 SPIN	D8 SNAP

Any pad, any of these 27 samples or your own (the sample editor): hit it, turn **PRESETS**. 12 bit at 26.04 kHz, pitched without interpolation.

Sound

Channels a pad plays on a channel 1–8 (OUT, CHAN); one sound at a time each: a new hit cuts the last (HAT and OHAT share 3)

1–2 a 4-pole resonant low-pass: open as CUT at the hit, closing two octaves as the sound decays (RESO)

3–6 · 7–8 a fixed low-pass · no filter

45 → 33 TRUNC, SPEED: played at 33/45 of its rate: lower, grainier. Own samples also at ×2 (the editor): an octave down on the pad

The knobs

A1 KICK **090**
CH1 CH2 CH3 CH4
100 100 100 100

KNOB 1–4 the **faders** of channels 1–4; **SEL** held: **5–8**, on any page. The LCD's four columns always say what the knobs do.

A page EDIT, FX, SEQ, GLO open one; untouched **12 s** (SETUP: BACK), or **HOME**: the faders again

SELECT tempo

ALGORITHM the sound to edit (A1 ... D8), without playing it

PRESETS **the sample** of the pad you hit last: one sample on as many pads as you like, each with its own TUNE, DECAY ...

MASTER the volume

Pages · KNOB 1 · 2 · 3 · 4

EDIT **WAVE** the pad's sample · COPY> pad · COPY (turn twice) · –

SOUND TUNE (semitones) · FINE · DECAY · LEVEL

TRUNC START · END · DIR (fwd / rev) · SPEED (45 / 33)

OUT CHAN · PAN · CUT · RESO (CUT / RESO on ch 1–2)

SENDS DRIVE · CHO · DLY · REV: **the effects of this pad**

FX **FILTER** **DJ filter** on the whole mix: left a low-pass, right a high-pass, centre OFF · RESO

CHORUS RATE · DEPTH · MIX

DELAY TIME (1/4 ... 16T, in tempo) · FDBK · COLOR · MIX

REVERB SIZE · DAMP · PRE (ms)

SEQ **LOOP** LOOP · BARS (AUTO, 1–32) · QUANT (AUTO CORRECT) · SWING 50–71 %

LOOP TOOLS CLEAR (turn twice) · COPY> loop · COPY (turn twice)

SONG STEP · LOOP · REPEAT (0: the song ends here) · SONG OFF / 1–4

GLO **SETUP** TEMPO · CLICK · BACK (6–60 s, OFF) · RESET (turn twice)

Each tap of EDIT, FX or SEQ: the next of its pages. The header says where you are (EDIT > SOUND), the tabs below show the others.

Make a beat

1. **REC** (it blinks: armed), **PLAY**: a bar of count-in.
2. Play kick and snare. **AUTO CORRECT** puts them on the grid.
3. **REC** again at the end: an empty loop (BARS **AUTO**) is now as long as your take.
4. Hats step by step: hit the hat, **hold SEQ**: the white keys are its 16 steps (lit = a hit), tap to set / clear; **OCT+** the next bar.
5. **REC** while it plays: overdub more on top; **REC** again: off.
6. Turn TUNE, DECAY (EDIT → SOUND) or CUT while recording: **the pad's hits keep what you turned** (a red dot in the step grid).
7. A chord: **OCT+**, white 9 (D1). Melodic: **ARP** (MULTI PITCH).
8. Another loop: a black key, record into it. Songs: SEQ → SONG.

Buttons

PLAY	run / stop (lit while it runs)
REC	stopped: armed (blinks); playing: overdub on / off; hold 2 s : clear the loop
EDIT + OCT–	undo the last clear / erase / copy (again: redo)
LFO + pad	erase : that pad's hits go as the playhead passes (stopped: all at once)
ENV	tap tempo (it blinks on the beat)
SAVE	save now; held + a black key : the loop into that loop; stopped and quiet for 3 s it saves by itself
HOME	the faders

Effects in 3 steps

1. Hit the pad (the snare).
2. **EDIT** until the LCD says **SENDS**.
3. KNOB 4 = REV, KNOB 3 = DLY. Shape them: **FX**.

In the browser (Chrome / Edge, USB):

zp12.designburgapps.com/editor drops your own samples onto the pads, **/backup** saves and restores everything. Back to sloopDX: its installer. No answer? Hold OCT– while switching on (USB rescue).