


## The keys



**White 1–8** pads of bank **A** (or **C**)

**White 9–16** pads of bank **B** (or **D**)

**OCT+** **OCT–** banks **C + D** / back to **A + B** (the LEDs A–D show which)

**black keys** **loops 1–11**: stopped at once; playing: from the end of the loop (its key blinks, the LCD says **LOOP 3 NEXT**). The loop playing is lit.

**ARP** **MULTI PITCH**: the last sound on all 27 keys, F4 (white 8) as tuned. ARP again: pads.

**USB MIDI** notes 36–67 play pads A1–D8

## The factory sounds

|                       |                                                    |                    |                    |                    |                      |                      |                    |
|-----------------------|----------------------------------------------------|--------------------|--------------------|--------------------|----------------------|----------------------|--------------------|
| <b>A1</b><br>KICK     | <b>A2</b><br>SNARE                                 | <b>A3</b><br>RIM   | <b>A4</b><br>CLAP  | <b>A5</b><br>HAT   | <b>A6</b><br>OHAT    | <b>A7</b><br>TOM L   | <b>A8</b><br>TOM H |
| <b>B1</b><br>CRASH    | <b>B2</b><br>RIDE                                  | <b>B3</b><br>COWBL | <b>B4</b><br>TAMB  | <b>B5</b><br>SHAKR | <b>B6</b><br>CONGA   | <b>B7</b><br>CLAVE   | <b>B8</b><br>WOOD  |
| <b>C1–C5</b><br>A1–A5 | <b>bank A lower, 45 → 33, the filter on ch 1–2</b> |                    |                    |                    | <b>C6</b><br>PNO Cm9 | <b>C7</b><br>PNO F13 | <b>C8</b><br>PIANO |
| <b>D1</b><br>EP Dm9   | <b>D2</b><br>EP Gm9                                | <b>D3</b><br>HORNS | <b>D4</b><br>VIBES | <b>D5</b><br>BASS  | <b>D6</b><br>SCRCH   | <b>D7</b><br>SPIN    | <b>D8</b><br>SNAP  |

Any pad, any of these 27 samples or your own (the sample editor): hit it, turn **PRESETS**. 12 bit at 26.04 kHz, pitched without interpolation.

## Sound

**Channels** a pad plays on a channel 1–8 (OUT, CHAN); one sound at a time each: a new hit cuts the last (HAT and OHAT share 3)

**1–2** a 4-pole resonant low-pass: open as CUT at the hit, closing two octaves as the sound decays (RESO)

**3–6 · 7–8** a fixed low-pass · no filter

**45 → 33** TRUNC, SPEED: played at 33/45 of its rate: lower, grainier. Own samples also at ×2 (the editor): an octave down on the pad

## The knobs

**A1 KICK** **090**  
CH1 CH2 CH3 CH4  
**100 100 100 100**

**KNOB 1–4** the **faders** of channels 1–4; **SEL** held: **5–8**, on any page. The LCD's four columns always say what the knobs do.

**A page** EDIT, FX, SEQ, GLO open one; untouched for **30 s** (GLO → SETUP → BACK: 6 s ... OFF), or **HOME**: the faders again

**SELECT** tempo

**ALGORITHM** the sound to edit (A1 ... D8), without playing it

**PRESETS** the **sample** of the pad you hit last: one sample on as many pads as you like, each with its own TUNE, DECAY ...

**MASTER** the volume

## Pages · KNOB 1 · 2 · 3 · 4

**EDIT WAVE** the pad's sample · COPY> pad · COPY (turn twice) · —

**SOUND** TUNE (semitones) · FINE · DECAY · LEVEL

**TRUNC** START · END · DIR (fwd / rev) · SPEED (45 / 33)

**OUT** CHAN · PAN · CUT · RESO (CUT / RESO on ch 1–2)

**SENDS** DRIVE · CHO · DLY · REV: **the effects of this pad**

**FX FILTER** **DJ filter** on the whole mix: left a low-pass, right a high-pass, centre OFF · RESO

**CHORUS** RATE · DEPTH · MIX

**DELAY** TIME (1/4 ... 16T, in tempo) · FDBK · COLOR · MIX

**REVERB** SIZE · DAMP · PRE (ms)

**SEQ LOOP** LOOP · BARS (AUTO, 1–32) · QUANT (AUTO CORRECT) · SWING 50–71 %

**LOOP TOOLS** CLEAR (turn twice) · COPY> loop · COPY (turn twice)

**SONG** STEP · LOOP · REPEAT (0: the song ends here) · SONG OFF / 1–4

**GLO SETUP** TEMPO · CLICK (off / rec / on) · BACK (pages: 6 / 15 / 30 / 60 s / OFF) · RESET (turn twice); the version top right

Each tap of EDIT, FX or SEQ: the next of its pages. The header says where you are (EDIT > SOUND), the tabs below show the others.

## Make a beat

1. **REC** (it blinks: armed), **PLAY**: a bar of count-in.
2. Play kick and snare. **AUTO CORRECT** puts them on the grid.
3. **REC** again at the end: an empty loop (BARS **AUTO**) is now as long as your take.
4. Hats step by step: hit the hat, **hold SEQ**: the white keys are its 16 steps (lit = a hit), tap to set / clear; **OCT+** the next bar.
5. **REC** while it plays: overdub more on top; **REC** again: off.
6. Turn TUNE, DECAY (EDIT → SOUND) or CUT while recording: **the pad's hits keep what you turned** (a red dot in the step grid).
7. A chord: **OCT+**, white 9 (D1). Melodic: **ARP** (MULTI PITCH).
8. Another loop: a black key, record into it. Songs: SEQ → SONG.

## Buttons

|                    |                                                                                                             |
|--------------------|-------------------------------------------------------------------------------------------------------------|
| <b>PLAY</b>        | run / stop (lit while it runs)                                                                              |
| <b>REC</b>         | stopped: armed (blinks); playing: overdub on / off; <b>hold 2 s</b> : clear the loop                        |
| <b>EDIT + OCT–</b> | <b>undo</b> the last clear / erase / copy (again: redo)                                                     |
| <b>LFO + pad</b>   | <b>erase</b> : that pad's hits go as the playhead passes (stopped: all at once)                             |
| <b>ENV</b>         | tap tempo (it blinks on the beat)                                                                           |
| <b>SAVE</b>        | save now; <b>held + a black key</b> : the loop into that loop; stopped and quiet for 3 s it saves by itself |
| <b>HOME</b>        | the faders                                                                                                  |

## Effects in 3 steps

1. Hit the pad (the snare).
2. **EDIT** until the LCD says **SENDS**.
3. KNOB 4 = REV, KNOB 3 = DLY. Shape them: **FX**.

**In the browser** (Chrome / Edge, USB):

**zp12.designburgapps.com/editor** drops your own samples onto the pads, **/backup** saves and restores everything. Back to sloopDX: its installer. No answer? Hold OCT– while switching on (USB rescue).

