

Command	Arguments	Returns	Description
set job	string: job-name	result	Select active job, by name.
get job		string: job-name	Get the name of the active job.
set exposure	int: exposure	result	Set the sensor exposure time. Specified in microseconds
get exposure		int: exposure	Get the sensor exposure time. Specified in microseconds
set gain	real: gain	result	Set the sensor gain factor.
get gain		real: gain	Get the sensor gain factor.
set imageTriggerMode	enum: imageTriggerMode [Input, None, Object, Command]	result	Set the image trigger mode.
get imageTriggerMode		enum: imageTriggerMode [Input, None, Object, Command]	Get the image trigger mode.
set laser	enum: enable [on, off]	result	Turn the laser on or off.
set laserThreshold	int: threshold	result	Set the intensity threshold for detecting the laser
get laserThreshold		int: threshold	Get the intensity threshold for detecting the laser
set profileDistance	real: distance	result	Set the distance between profile acquisitions
get profileDistance		real: distance	Get the distance between profile acquisitions
set profileTriggerMode	enum: mode [Encoder, FreeRunning]	result	Set the profile trigger mode

get profileTriggerMode		enum: mode [Encoder, FreeRunning]	Get the profile trigger mode
set pulsesPerMM	real: pulses	result	Set the encoder pulses per mm. Relevant only when profileTriggerMode is Encoder
get pulsesPerMM		real: pulses	Get the encoder pulses per mm. Relevant only when profileTriggerMode is Encoder
set speed	real: speed	result	Specify the object movement speed. Relevant only when profileTriggerMode is FreeRunning
get speed		real: speed	Get the specified object movement speed. Relevant only when profileTriggerMode is FreeRunning
set triggerDelayTime	int: delay	result	Specify the trigger delay in ms. Relevant only when triggerDelayMode is ms
get triggerDelayTime		int: delay	Get the trigger delay in ms. Relevant only when triggerDelayMode is ms
set triggerDelayTrack	int: delay	result	Specify the trigger delay in mm. Relevant only

			when triggerDelayMode is mm
get triggerDelayTrack		int: delay	Get the trigger delay in mm. Relevant only when triggerDelayMode is mm
set triggerDelayMode	enum: mode [ms, mm]	result	Specify whether triggerDelayTrack (mm) or triggerDelayTime (ms) is used
get triggerDelayMode		enum: mode [ms, mm]	Get whether triggerDelayTrack (mm) or triggerDelayTime (ms) is used
echo	string: message	string: message	Returns the input message
trigger			Trigger an image acquisition. Usable only when imageTriggerMode is Command
save-to-flash		result	Save the current configuration persistently
help		string	Retrieve command channel help text