



PIN: $\varnothing 4,96$
(g6: $-0,04 -0,16$)

2x 695zz
2x M5 Shim

2x M3 Inserts

M3x10 or M3x8

2x M3x30
2x M3 Shim

2x 6x3 Magnets

Housing Cover

Magnetic Cover 3
(Squared Design)

Magnetic Cover 2
(Angled Design)

Magnetic Cover 1
(Round Design)

WIP - Work in Progress

Left & Right side are identical.
Just print it twice!

Housing:
- Printable from back to front
- No supports!
- You need for Bottom&Top (z_belt_clip_lower).

Inlet:
- Printable from side (the other side, not this side)
- No Supports
- Insert the M3-inserts, after you putted the bearings and Pin inside!
If you insert the M3-inserts first, you won't be able to put the Pin inside!