

First you 3D print your parts of the industrial robotic arm, after you 3D printed the parts, you place the parts in front of you in order of which you're going to assemble it.

1st your going start with the base bolt the waist to the base so we can connect the first part of the arm after that connect the second part of the arm then you connect the gripper mechanism into the last part of the arm.