



- H4 MountingHole
- H3 MountingHole
- H2 MountingHole
- H1 MountingHole

Pulse is 400ns, way too short to be visible so invert the pulse use a 555 as monostable to extend it to ~1/4 sec so humans can see it.

Sheet: /

File: SA22C-PulseExtender.kicad\_sch

**Title: SA22C - PPS\_OUT pulse extender**

Size: A4

Date: 2024-04-12

Rev:

KiCad E.D.A. 8.0.1

Id: 1/1