



An antenna may be used instead of C3. This is used to radiate higher frequencies to get a cleaner signal at 20 MHz.

WARNING: Using ethernet without magnetic isolation is dangerous. Do so with caution only once you are absolutely positive the other side of the ethernet is isolated.

WARNING: The ESP will be competing against the serial driver. This will cause degradation in signal and may damage the serial driver.

NOTE: Using ethernet without a driver is fraught with peril.

NOTE: The resistors and capacitors selected here were ones I found happened to kind of work (<60% packet loss) you may find better ones. If you do, please tell me.

CC 3.0 BY

(C) 2016 <>< Charles Lohr

File: nodemcu-ethernet.sch

Sheet: /

Title: NodeMCU 10-Base-T Wiring Diagram

Size: User

Date: 30 mar 2016

Rev: -

KiCad E.D.A.

Id: 1/1