



PT5, PT6, PT7, PT8, PT9, PT10 WILL HAVE TO BE LOOPED BETWEEN THE TWO CONNECTORS.
26 PIN CONNECTOR DOES NOT HAVE ENOUGH PASSTHROUGH LINES



comma.ai
you can copy this!

,

TITLE: Subaru_C_Harness

Design by:

REV:

Date: 7/5/22 5:05 PM

Sheet: 1/1