



PT5, PT6, PT7, PT8, PT9, PT10, PT11, PT12, PT13
WILL HAVE TO BE LOOPED BETWEEN THE TWO
CONNECTORS AT 26 PIN MOLEX DOES NOT HAVE ENOUGH PASSTHROUGH LINES

GND WIRE ON CONNECTOR TO MODULE WILL NEED TO HAVE TWO WIRES IN ONE
TERMINAL. A IGN_GND WIRE WILL NEED TO BE RAN TO 26 PIN CONNECTOR

comma.ai
you can copy this!

9

TITLE: Ford_Q4_Harness

Design by:

REV:

Date: 9/20/22 2:45 PM

Sheet: 1/1