



PT5, PT6, PT7, PT8, PT9, PT10, PT11, PT12,
WILL HAVE TO BE LOOPED BETWEEN THE TWO
CONNECTORS AT 26 PIN MOLEX DOES NOT HAVE ENOUGH PASSTHROUGH LINES

comma.ai
you can copy this!

,

TITLE: Ford_Q4_Harness

Design by:

REV:

Date: 7/19/23 10:00 AM

Sheet: 1/1