

Instructions for using the pot mould

Step 1.Remove all bolts and disassemble.

Step 2.The middle portion is covered in petroleum jelly (includes the small triangle on the top).

Step 3.Reassemble all the parts.

Step 4.Prepare your cement and sand mix (50/50). Do not use too much water. You'll want to get a thick consistency (cookie dough). If it is too runny, add some more sand or cement.

Step 5.Mixture is cast into mould.

Step 6.Knock gently at the bottom with your knuckles to remove any air pockets.

Step 7.Place it on a level surface to set for 12 hours.

Step 8.When the pot is completely dry, remove the sides and let set for another 12 hours.

Step 9.Use a sharp putty knife to loosen where the edge meets the base, and pull the pot free.