

HOW TO RENAME ON/OFF BUTTONS?

1. Open device sketch in ARDUINO IDE software.
2. Find this place in the code ->

```
if (relay_1_state == 0)
{ web += "<p><a href=\"/1_on\"><button class=\"button button2\"><b>OFF</button></a></p>"; }
else
{ web += "<p><a href=\"/1_off\"><button class=\"button\"><b>ON</button></a></p>"; }
```

3. Rename button name as you need ->

```
if (relay_1_state == 0)
{ web += "<p><a href=\"/1_on\"><button class=\"button button2\"><b>BADROOM LIGHTS OFF</button></a></p>"; }
else
{ web += "<p><a href=\"/1_off\"><button class=\"button\"><b>BADROOM LIGHTS ON</button></a></p>"; }
```

4. Rename all buttons as you need. Then compile new sketch and upload it to the Wi-Fi esp8266 board.
Now new renamed buttons are available ->

WIFI 8 Channel Relay

BADROOM LIGHTS ON

OFF

OFF

OFF

OFF

OFF

OFF

OFF



5. Enjoy ;)