



In this example, potentiometer values are read in through an 'Analog In' pin. The values are then used to control the modulation of an LED on a PWM pin. Related examples: <http://arduino.cc/en/Tutorial/AnalogInput> <http://arduino.cc/en/Tutorial/Fading>

