



Please do not start assembling your case until indicated in the slides!

You will not be able to program it without taking it off otherwise.