

Hazard Recognition

Exposed wiring, overloaded circuits, and improper grounding are primary risks.

Safe Work Practices

- De-energize circuits before maintenance.
- Use insulated tools and voltage testers.
- Follow NFPA 70E arc-flash boundaries.