

- V1.0
- Initial Version
- V2.0
1. Add CANBUS interface
 2. Add 20*30 heat sinks
 3. Replace with a 4Pin connector, fixed with screws
 4. Add optional USB and CANBUS interfaces
 5. Lead out all IO ports of RP2040
 6. Preset thermistor temperature measurement circuit