

LOWER FLOOR

Back

⚠ This side up ⚠  
Glue face to IR Alignment Panel

Right

Towards Front Edge

Place Fly Tray Holder here

⚠ This side up ⚠  
Glue face to IR Alignment Panel

LOWER FLOOR

Inner Front

IR ALIGNMENT PANEL

Towards Right Edge

⚠ This side down ⚠  
Glue face to Lower Floor

FLY TRAY HOLDER

⚠ This side down ⚠  
Glue face to IR Diffuser

Towards Back Edge

IR ALIGNMENT PANEL

Towards Left Edge

⚠ This side down ⚠  
Glue face to Lower Floor