



# INSTRUCTIONS:

FOR THE FOUR (4X) IGUS LINEAR BEARINGS  
FOR THE X AXIS, YOU WILL NEED TO DRILL AND TAP  
AT LEAST TWO (2X) EXTRA HOLES ON THE TOP SURFACE.

FOR THE TWO (2X) BEARINGS AT THE BACK  
OF THE ROBOT, AN ADDITIONAL HOLE ON THE FACE WITH  
THE SMALL LIP IS REQUIRED. MEASURE THE 15MM DISTANCE  
FROM OPPOSITE ENDS FOR THE TWO BEARINGS.

