

revision 4_2_16_7PM

I made some changes :

1. when eeprom is empty it will load base 1 code.
2. "set baseCode=4" is now storing your desired baseCode
3. "getBase" will get correct base code from the eeprom

Check it out and let me know..

John