



RubyLink serial pins:
JTAG 20 pins: probe RX – pin 18, probe TX – pin 20;
To connect these pins to J9, short 1–2 and 9–10 on J8.

MioLink serial pins:
JTAG 10 pins: probe RX – pin 6, probe TX – pin 8;
To connect these pins to J9, short 3–4 and 11–12 on J8.

J-Link serial pins:
JTAG 20 pins: probe RX – pin 17, probe TX – pin 5;
JTAG 10 pins: probe RX – pin 7, probe TX – pin 8;
To connect these pins to J9, short 5–6 and 13–14 on J8.

ST-Link v3 serial pins:
STDC 14 pins: probe RX – pin 14, probe TX – pin 13;
To connect these pins to J9, short 7–8 and 15–16 on J8.

Designed by: Dmitry Rezvanov (<https://github.com/Misaka0x2730>)

Sheet: /
File: MioLink_adapter.kicad_sch

Title: MioLink_adapter rev. A

Size: A4 Date: 2024–09–14
KiCad E.D.A. 8.0.5

Rev:
Id: 1/1