




## 2020 Extrusion Covers for:

~~All Voron Printers~~

~~Voron 2 250mm 3D Printers~~





~~Voron 2 300mm 3D Printers~~

Voron 2 350mm 3D Printers








Insert  
2 M3x8 SHCS &  
T-Nuts into  
all 4 lower corners





Add the rest of the lower section  
with M3x8 SHCS & T-Nuts in the same fashion






Apply 3M 468MP Adhesive  
to All 6 Hinge Arms



Fasten Hinge Arm to  
hinge body with  
(2) M2x16 SHCS






Repeat Process with  
remaining hinges  
(6) Total



NOTE: While it may be messy, silicone or other viscous glue would work.




Slide Completed Hinges  
& 140mm Sections onto  
The front extrusions.








Slide Rear Sections  
onto extrusions




Rear Section



Front Section




BEFORE



AFTER




Slide in Side & Rear  
Acrylic Panels





Remove Upper Frame Sections  
one at a time and slide  
the remaining sections  
into place.

*NOTE: Don't forget to slide  
in the top panel before  
completing the final side.*



BEFORE



AFTER






Gently tap M3 Heat Set Inserts into the top of each vertical extrusion.

Fasten Top Corners with M3x12 SHCS

Position Doors and  
adhere to Hinge Arms



BEFORE



AFTER



Add Magnets & Door Handles

---

*- Jay*

