

32. Finally, plug the cable in and attach the blunt end to the tree using the provided rubber bands.
33. You're done!



This kit is certified open hardware.