

UrbanAnt Assembly Guide

1. Gluing the box

Parts needed:

Bottom_Red

Front_Red

Rear_Red

Side1_Red

Side2_Red



Additional material:

Paper tape

Epoxy glue

Instructions:

Put the involved parts together. Use paper tape from the outside to make it stay steadily. Apply (two-component epoxy resin) glue from the inside along the gaps. After the glue has cured, the paper tape can be removed.



2. Adding brass inserts

Parts needed:

Frame

Additional material and tools:


Drill 2.5-2.7mm

Soldering iron

M2 Brass inserts x4

Instructions:

Predrill all four holes on the sides of the frame. Insert the brass inserts using soldering iron.



3. Adding the covers

Parts needed:

Frame


Face_Red

Additional material and tools:

Epoxy glue

Instructions:

Place and glue the face plate into the frame.



4. Gluing the buttons

Parts needed:

Non-latching buttons x2


VoteButton x2

Additional material and tools:

Epoxy glue

Instructions:

Glue the 3D-printed button covers on the buttons. You might need to press them together until the glue cures.



5. Putting UrbanAnt together

Parts needed:

The previous assemblies

Internal electronics assembled based on the GitHub Wiki

Front_Seethrough

Additional material and tools:

Epoxy glue

M2 screws x4

Instructions:

Place and mount the buttons. Glue the see-through face on the box, and sink the face assembly into the box. You can secure it with the four screws from the sides. A paper with the message can be added using the slot on the side of the box.

