

TRIPLE S *Customs*

**FORD ECONOLINE VAN 1989-2006
VEHICLE WIRING**

WIRING INFORMATION: 1989 Ford Econoline

| WIRE | WIRE COLOR | WIRE LOCATION |
|-------------------------|------------------|--|
| 12V CONSTANT WIRE | YELLOW | Ignition Harness |
| STARTER WIRE | WHITE/PINK | Ignition Harness |
| IGNITION WIRE | RED/GREEN | Ignition Harness |
| ACCESSORY WIRE | GRAY/YELLOW | Ignition Harness |
| POWER DOOR LOCK (+) | PINK/YELLOW | Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (+) | PINK/GREEN | Harness Coming Into Vehicle From Driver's Door |
| PARKING LIGHTS (+) | BROWN | Harness In Driver's Kick Panel Running To Vehicle's Rear |
| HEADLIGHTS (+) | RED/YELLOW | At Headlight Switch |
| DOOR TRIGGER (+) | BLACK/LT. BLUE | At Door Pin Switch Or At Under Dash Light |
| TACHOMETER WIRE | DK. GREEN/YELLOW | At Ignition Coil |
| BRAKE WIRE (+) | RED/LT. GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | YELLOW/LT. GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION: 1990 Ford Econoline

| WIRE | WIRE COLOR | WIRE LOCATION |
|-------------------------|------------------|--|
| 12V CONSTANT WIRE | YELLOW | Ignition Harness |
| STARTER WIRE | WHITE/PINK | Ignition Harness |
| IGNITION WIRE | RED/GREEN | Ignition Harness |
| ACCESSORY WIRE | GRAY/YELLOW | Ignition Harness |
| POWER DOOR LOCK (+) | PINK/YELLOW | Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (+) | PINK/GREEN | Harness Coming Into Vehicle From Driver's Door |
| PARKING LIGHTS (+) | BROWN | Harness In Driver's Kick Panel Running To Vehicle's Rear |
| HEADLIGHTS (+) | RED/YELLOW | At Headlight Switch |
| DOOR TRIGGER (+) | BLACK/LT. BLUE | At Door Pin Switch Or At Under Dash Light |
| TACHOMETER WIRE | DK. GREEN/YELLOW | At Ignition Coil |
| BRAKE WIRE (+) | RED/LT. GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | YELLOW/LT. GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION: 1991 Ford Econoline

| WIRE | WIRE COLOR | WIRE LOCATION |
|-------------------------|------------------|--|
| 12V CONSTANT WIRE | YELLOW | Ignition Harness |
| STARTER WIRE | WHITE/PINK | Ignition Harness |
| IGNITION WIRE | RED/GREEN | Ignition Harness |
| ACCESSORY WIRE | GRAY/YELLOW | Ignition Harness |
| POWER DOOR LOCK (+) | PINK/YELLOW | Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (+) | PINK/GREEN | Harness Coming Into Vehicle From Driver's Door |
| PARKING LIGHTS (+) | BROWN | Harness In Driver's Kick Panel Running To Vehicle's Rear |
| HEADLIGHTS (+) | RED/YELLOW | At Headlight Switch |
| DOOR TRIGGER (+) | BLACK/LT. BLUE | At Door Pin Switch Or At Under Dash Light |
| TACHOMETER WIRE | TAN/YELLOW | At Ignition Coil |
| BRAKE WIRE (+) | RED/LT. GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | YELLOW/LT. GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION 1992 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| HOOD PIN (-) | BROWN/WHITE | At Factory Hood Pin Switch Or At Factory Anti-Theft Module Behind Driver's B Pillar |
| DOMELIGHT SUPERVISION (+) | | Use Door Trigger Wire |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar |
| TACHOMETER | GRAY/ORANGE | At Ignition Coil |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION 1993 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| HOOD PIN (-) | BROWN/WHITE | At Factory Hood Pin Switch Or At Factory Anti-Theft Module Behind Driver's B Pillar |
| DOMELIGHT SUPERVISION (+) | | Use Door Trigger Wire |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar |
| TACHOMETER | GRAY/ORANGE | At Ignition Coil |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION 1994 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| HOOD PIN (-) | BROWN/WHITE | At Factory Hood Pin Switch Or At Factory Anti-Theft Module Behind Driver's B Pillar |
| DOMELIGHT SUPERVISION (+) | | Use Door Trigger Wire |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar |
| TACHOMETER | GRAY/ORANGE | At Ignition Coil |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION 1995 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| HOOD PIN (-) | BROWN/WHITE | At Factory Hood Pin Switch Or At Factory Anti-Theft Module Behind Driver's B Pillar |
| DOMELIGHT SUPERVISION (+) | | Use Door Trigger Wire |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar |
| TACHOMETER | GRAY/ORANGE | At Ignition Coil |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION 1996 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| DOMELIGHT SUPERVISION (+) | | Use Door Trigger Wire |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION 1997 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

WIRING INFORMATION 1998 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |
| This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system. | | |

WIRING INFORMATION 1999 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |
| This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system. | | |

WIRING INFORMATION 2000 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |
| This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system. | | |

WIRING INFORMATION 2001 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |
| This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system. | | |

WIRING INFORMATION 2002 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| DOMELIGHT SUPERVISION (+) | | Use Door Trigger Wire |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system.

WIRING INFORMATION 2003 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|--------------------|---|
| 12V CONSTANT | YELLOW | Ignition Harness |
| 12V IGNITION | RED/GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Switch Or Driver's Kick Panel |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN | At Harness In Driver's Kick Panel |
| DOOR TRIGGER (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| DOMELIGHT SUPERVISION (+) | | Use Door Trigger Wire |
| FACTORY ALARM ARM (+) **Must be pulsed with lock** | RED/YELLOW | At Factory Anti-Theft Module Behind Driver's B Pillar |
| FACTORY ALARM DISARM (-) | DK.GREEN/PURPLE | At Factory Anti-Theft Module Behind Driver's B Pillar Or Harness In Driver's Kick Panel |
| TACHOMETER | WHITE/PINK | Connector Labeled 'CTO Test' Above Brake Booster |
| BRAKE WIRE (+) | LT.GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | RED/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | YELLOW/BLACK | Harness In Driver's Kick From Driver Door |

This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system.

WIRING INFORMATION 2004 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|---------------------|---|
| 12V CONSTANT | LT.GREEN/PURPLE | Ignition Harness |
| 12V IGNITION | PINK/LT.GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| SECOND ACCESSORY | RED | Ignition Harness |
| THIRD ACCESSORY | BLACK/LT.GREEN | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Behind Headlight Switch |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED or ORANGE/BLACK | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN or YELLOW/RED | At Harness In Driver's Kick Panel |
| LEFT FRONT DOOR TRIGGER (-) | RED/PINK | At Module In Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/WHITE | At Module In Passenger Kick Panel |
| SLIDING DOOR TRIGGER (-) | WHITE | At Module In Passenger Kick Panel |
| DOMELIGHT SUPERVISION (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| SIDE HINGE DOORS | Tied in with doors | Must Have Factory Pin Switch |
| TACHOMETER | WHITE/PINK | At PCM Close to Brake Master Cylinder |
| BRAKE WIRE (+) | DARK GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | WHITE/YELLOW | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN/LT.BLUE | Harness In Driver's Kick From Driver Door |
| This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system. | | |

WIRING INFORMATION 2005 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|---------------------|---|
| 12V CONSTANT | LT.GREEN/PURPLE | Ignition Harness |
| 12V IGNITION | PINK/LT.GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| SECOND ACCESSORY | GRAY/YELLOW | Ignition Harness |
| THIRD ACCESSORY | BLACK/LT.GREEN | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Behind Headlight Switch |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED or ORANGE/BLACK | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN or YELLOW/RED | At Harness In Driver's Kick Panel |
| LEFT FRONT DOOR TRIGGER (-) | RED/PINK | At Module In Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/WHITE | At Module In Passenger Kick Panel |
| SLIDING DOOR TRIGGER (-) | WHITE | At Module In Passenger Kick Panel |
| DOMELIGHT SUPERVISION (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| SIDE HINGE DOORS | Tied in with doors | Must Have Factory Pin Switch |
| TACHOMETER | WHITE/PINK | At PCM Close to Brake Master Cylinder |
| BRAKE WIRE (+) | DARK GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | WHITE/YELLOW | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN/LT.BLUE | Harness In Driver's Kick From Driver Door |
| This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system. | | |

WIRING INFORMATION 2006 Ford Econoline

| WIRE | COLOR | LOCATION |
|---|---------------------|---|
| 12V CONSTANT | LT.GREEN/PURPLE | Ignition Harness |
| 12V IGNITION | PINK/LT.GREEN | Ignition Harness |
| STARTER | WHITE/PINK | Ignition Harness |
| 12V ACCESSORY | GRAY/YELLOW | Ignition Harness |
| SECOND ACCESSORY | GRAY/YELLOW | Ignition Harness |
| THIRD ACCESSORY | BLACK/LT.GREEN | Ignition Harness |
| PARKING LIGHTS (+) | BROWN | Behind Headlight Switch |
| POWER DOOR LOCK (5-wire reverse polarity- use passenger switch to test) | RED or ORANGE/BLACK | At Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (5-wire reverse polarity- use passenger switch to test) | BROWN or YELLOW/RED | At Harness In Driver's Kick Panel |
| LEFT FRONT DOOR TRIGGER (-) | RED/PINK | At Module In Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/WHITE | At Module In Passenger Kick Panel |
| SLIDING DOOR TRIGGER (-) | WHITE | At Module In Passenger Kick Panel |
| DOMELIGHT SUPERVISION (+) | BLACK/LT.BLUE | At Door Pin Switch Or Under Dash Light |
| REAR DOOR TRIGGER | Tied in with doors | Must Have Factory Pin Switch |
| SIDE HINGE DOORS | Tied in with doors | Must Have Factory Pin Switch |
| TACHOMETER | WHITE/PINK | At PCM Close to Brake Master Cylinder |
| BRAKE WIRE (+) | DARK GREEN | At Brake Pedal Switch |
| HORN TRIGGER (-) | DK.BLUE | Harness At Steering Column |
| LEFT FRONT WINDOW UP | WHITE/BLACK | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | YELLOW | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | WHITE/YELLOW | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN/LT.BLUE | Harness In Driver's Kick From Driver Door |
| This vehicle may be equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system. | | |