



Different PWM pins have different frequencies and it is necessary to match frequencies so that the robot drives straight.
The nano has two interrupt pins, pins 2 and 3. It is better to avoid these pins when possible as they are limited and have specific uses.

Sheet: /

File: Drivetrain.sch

Title: SCR Basic Drivetrain Schematic

Size: A4

Date:

KiCad E.D.A. kicad (5.0.2)-1

Rev:

Id: 1/1