



1. When Skip mode is selected, AC simulation may fail when the Load Current is low enough to engage Skip mode. Skip mode is hysteretic and there is no AC Loop to measure.
2. FB1in, FB1Out, FB2In, and FB2Out are fictitious pins. They are needed for AC analysis measurements on the internal feedback loop inside the IC.