



Place all markings on back (including pcb order number).
 Add flammability rating marking on back, such as 94V-0.
 The front-side surface is cosmetic - reject units with scratches and blemishes.

We recommend making the front-side layer chassis ground.
 Add 1.25 mm of exposed chassis ground copper on back layer edge
 that is via stitched to front chassis ground plane.