

Action	Object	Change Document	Status
Add Pins To Nets			
Add	BCK1-VCC to V_5.5	In SuperBot_Pcb.PcbDoc	
Add	IRF1-GND to GND	In SuperBot_Pcb.PcbDoc	
Add	IRF1-Signal to NetIRF1_Signal	In SuperBot_Pcb.PcbDoc	
Add	IRF1-VCC to V_5.5	In SuperBot_Pcb.PcbDoc	
Add	SW1-4 to M3_EN	In SuperBot_Pcb.PcbDoc	
Add	SW1-5 to NetR53_1	In SuperBot_Pcb.PcbDoc	
Add	SW1-6 to NetESP1_28	In SuperBot_Pcb.PcbDoc	
Add	SW1-7 to M2_EN	In SuperBot_Pcb.PcbDoc	
Add	SW1-8 to NetR53_1	In SuperBot_Pcb.PcbDoc	
Add	SW1-9 to NetESP1_29	In SuperBot_Pcb.PcbDoc	
Add	SW1-10 to M1_EN	In SuperBot_Pcb.PcbDoc	
Add	SW1-11 to NetR53_1	In SuperBot_Pcb.PcbDoc	
Add	SW1-12 to NetESP1_30	In SuperBot_Pcb.PcbDoc	
Add	SW2-1 to BMS_EN2	In SuperBot_Pcb.PcbDoc	
Add	SW2-2 to NetR58_1	In SuperBot_Pcb.PcbDoc	
Add	SW2-3 to CH_1.5	In SuperBot_Pcb.PcbDoc	
Add	SW2-4 to BMS_EN1	In SuperBot_Pcb.PcbDoc	
Add	SW2-5 to NetR57_1	In SuperBot_Pcb.PcbDoc	
Add	SW2-6 to CH_0.5	In SuperBot_Pcb.PcbDoc	
Add	SW2-7 to TRST	In SuperBot_Pcb.PcbDoc	
Add	SW2-9 to EN	In SuperBot_Pcb.PcbDoc	
Add	SW2-10 to EN	In SuperBot_Pcb.PcbDoc	
Add	SW2-11 to NetR55_1	In SuperBot_Pcb.PcbDoc	
Add	SW2-12 to NetR54_1	In SuperBot_Pcb.PcbDoc	
Add	T1-BASE to NetR47_2	In SuperBot_Pcb.PcbDoc	
Add	T1-CLCTR to EN	In SuperBot_Pcb.PcbDoc	
Add	T1-EMTTR to ESP_CTS	In SuperBot_Pcb.PcbDoc	
Add	T2-BASE to NetR48_2	In SuperBot_Pcb.PcbDoc	
Add	T2-CLCTR to IO0	In SuperBot_Pcb.PcbDoc	
Add	T2-EMTTR to NetR47_1	In SuperBot_Pcb.PcbDoc	
Add Component Class Members			
Add	SW1 to SuperBot_Sheet_main	In SuperBot_Pcb.PcbDoc	
Add	SW2 to SuperBot_Sheet_main	In SuperBot_Pcb.PcbDoc	
Add Rooms			
Add	Room Batmngt (Scope=InComponentClass("Batmngt")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room ControllerPower (Scope=InComponentClass("ControllerPower")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room MPU9250 (Scope=InComponentClass("MPU9250")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room Superbot_hbridge_mk3(Scope=InComponentClass("Superbot_hbridge_mk3")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room Superbot_LEDS (Scope=InComponentClass("Superbot_LEDS")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room Superbot_motor_boost_mk2(Scope=InComponentClass("Superbot_motor_boost_mk2")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room SuperBot_Sensors (Scope=InComponentClass("SuperBot_Sensors")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room SuperBot_Sheet_main(Scope=InComponentClass("SuperBot_Sheet_main")) TopLayer	To SuperBot_Pcb.PcbDoc	
Add	Room Superbot_USB (Scope=InComponentClass("Superbot_USB")) TopLayer	To SuperBot_Pcb.PcbDoc	