

One of the most disruptive forms of noise

Random spikes of power that can destroy one or more bits of information

Difficult to remove from an analog signal because it may be hard to distinguish from the original signal

Impulse noise can damage more bits if the bits are closer together (transmitted at a faster rate)