



Midiverse Modular

MVM001 – Multiple

Build Guide

Thanks for choosing this kit and supporting Midiverse Modular!

The MVM001 Multiple is a simple DIY build suitable for beginners and more experienced builders. This guide provides instructions on how to complete this build.

This kit comes with the following parts:

BOM	Qty
Multiple PCB	1
Multiple Panel	1
3.5mm Jacks	8



Populate the board with the 8 jacks. Before soldering the jacks, be sure to attach the front panel by loosely tightening the nuts. This step is very important as it is difficult to align the jacks with the holes if the front panel is not attached.

Once the panel is attached, flip the module over and solder the jacks in place. Next, tighten down the nuts on the front panel. Clip the leads on the jacks. Finally, reflow all the solder joints. You're finished!

