

Procedure for loading HPLC samples in autosampler

DO NOT FORGET TO SET THE TRAY TYPE IN THE AUTOSAMPLER!

So, do you play any instruments?



Vial Trays Layout

Tray B Part 1

| | | | | | | | |
|------------|----------|---------|---------|-----------|-----------|--|--|
| STD0_HClO4 | STD1_100 | STD2_50 | STD3_25 | STD4_12.5 | STD5_6.25 | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

96-Well Plate Trays Loading Protocol

96-Well plate A should be loaded in: **Tray R**

96-Well plate B should be loaded in: **Tray G**

96-Well plate C should be loaded in: **Tray R**