

Bess Operations Manual

BESS Operational Guidelines: - Optimal SoC window: 20%–80% for cycle life maximization. - Charge/discharge efficiency affected by C-rate and temperature. - Curtailment mitigation strategy: absorb excess PV into storage with predictive dispatch.