

Quantizing the Read Voltage since we need to convert it to digital then there is a range it should be in.

So The upper point of the range is our reference point which is 5V, so we multiply with 5 and then divide by the number of levels we have, here we have 10 bits to use to encode the value hence we divide by $2^{10} = 1024$ levels.