

Connect()



Cleanup Existing STA
Interfaces



Set network.wwan and
wireless.wifinet0 UCI
settings



Set SSID, BSSID, and
Encryption



Commit UCI Changes



Reload WiFi



Verify Connection

