


TODO: Add SATA power connector

Maybe use a zero ohm here



TODO: Should I connect the screw holes to ground? - <https://superuser.com/questions/1138512/what-exactly-is-grounded-through-motherboard-standoffs>

Screw holes matching those on a ATX motherboard. So the board can be secured to a motherboard standoff or cable-tied to the case See [https://en.wikipedia.org/wiki/Computer\\_case\\_screws#Motherboard](https://en.wikipedia.org/wiki/Computer_case_screws#Motherboard)

Mounting hole ##6-32 UNC    Mounting hole ##6-32 UNC

