

Bonus Tolerance Example

Position: $\varnothing 0.4$ @ MMC | Hole Size: $\varnothing 10 \pm 0.2$

