

The layout is intended for manual routing on a prototyping board!
 The unrouted wires have to be added manually with mod wires!





