

Fly wire  
 R6 top or R1 to U1 pin 3  
 U1 pin 2 to R8  
 U1 pin 5 to R10  
 U1 pin 6 to R10

cut - X  
 R6 to U1 pin 2  
 close to U1 pin 6 pad, but keep U1 pin 1  
 U1 pin 3 to R8  
 U1 pin 5 to R10  
 U1 pin 6 to R10

TechConficio © 2019



