



Assembly

Note: The button labels are flipped. This means that the buttons labeled "DPAD" are actually the buttonpad, and vice versa.

Also, the screen wires do need to stretch all the way across the screen's length.

Trimpot can go on either side, but the RPi Zero needs the headers soldered on backwards ( poking out the back, rather than the front)

The front has the PAM8302 Chip on it. This is the side the buttons should be pressed on, and the screen should be facing

