


Usually for digital pins, we write `digitalWrite(13, HIGH)` . To do that with analogue pins, simply use digits 14 to 19.

Pin 14 being A0, pin 15 being A1, and so on. For example, you could write `digitalWrite(14, HIGH)` , or you can also write `digitalWrite(A0, HIGH)` . Both do the same thing.

TITLE: 8 IR ARRAY LINE FOLLOWER CIRCUIT SCHEMATICS		REV: 1.0
 Front	Company: CERBERUS	Sheet: 1/1
	Date: 2021-01-07 Drawn By: Ayan Saha	