



## PROCEDURE

- Run the amplifier for 5-10 minutes to warm it up with no speakers connected.
- Measure the OFFSET as pictured. Adjust the OFFSET trimmers to read 0V
- Measure the BIAS as pictured and adjust the BIAS trimmers to read 10mV
- Check OFFSET and BIAS again after a few minutes and re-adjust as necessary.