

OpenRC Experimental Shocks

While in use, there is a high level of stress on the upper and lower joint and because of that i've printed all parts in Nylon. Despite that the only thing that absolutely must be printed in Nylon is the spring.

Use an L-Shaped Allen Key to screw M3x50mm screw in the bottom. You will probably need to compress the spring while doing this.

Then secure the lid with two M3 screws.

Hexagon Socket Pan Head Cap Screw ISO 7380 - M3 × 6

Lid

