



Essential pins for programming and running

VDD pins	= +3.3V (3.0-3.6V)
CH_PD	= H (10k pull-up)
IO15	= L (10k pull-down)
Tx0-IO1	= To Rx of programmer
Rx0-IO3	= To Tx of programmer
IO0	= To programmer (Nodemcu circuit)
Reset	= To programmer (Nodemcu circuit)

Mini-Board for ESP8285	
Markus Bärtschi markus@markus.org Rev 1.0	
esp8285-miniboard-v1.0	
20.07.16 16:17	
Sheet: 1/1	