

## Test mode and testing methods:

### Deep sleep :

1.Reset board 2.Enter the command "tickless" in the command line.

### DTIM:

1.Reset board

2.

ADV = 2S: Enter the command "ble\_start\_adv 0 0 0x0c80 0x0c80 " in the command line.

ADV = 500MS: Enter the command "ble\_start\_adv 0 0 0x0320 0x0320" in the command line.

### Benchmark:

Mode	uA
Deep sleep	50
ADV = 2S	367
ADV = 500ms	1300