



$$V_{OUT} = ((I_{LOAD} * R_{SENSE}) * GAIN) + V_{REF}$$

$$GAIN=500V/V$$



AE01001211		
-		
-		
-		
astroelectronic		
Sheet: /		
File: ZXCT211.kicad_sch		
Title: 26V, Zero-Drift, High-Precision Current Monitor. 500V/V.		
Size: A4	Date: 2025-06-19	Rev: 1
KiCad E.D.A. 9.0.2	Id: 1/1	